688.145 **SALAMANDER -** SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	Z-EB450-001	BOTTOM BOX	1
2	Z-EB450-002	BOTTOM BOARD	1
3	Z-EB450-003	TERMINAL CERAMIC HOLDER	1
4	Z-EB450-004	RUBBER FOOT	4
5	Z-EB450-005	CROSS HEAD SCREW	10
6	Z-EB450-006	HEATING INDICATOR	1
7	Z-EB450-007	CROSS HEAD SCREW	2
8	Z-EB450-008	THERMOSTAT	1
9	Z-EB450-009	POWER INDICATOR	1
10	Z-EB450-010	CRUMB TRAY	1
11	Z-EB450-011	S/S MESH	1
12	Z-EB450-012	CROSS HEAD SCREW	10
13	Z-EB450-013	PRESS STRAP FOR HEATING ELEMEN	1
14	Z-EB450-014	HEATING ELEMENT	1
15	Z-EB450-015	UPPER BOX	1
16	Z-EB450-016	CROSS HEAD SCREW	2
17	Z-EB450-017	HANDLE	1
18	Z-EB450-018		1
19	Z-EB450-019	UPPER BOTTOM PLATE	1
20	Z-EB450-020	DUMMY PLATE FOR GLASS WOOL	1
21	Z-EB450-021	UPPER BOX COVER	1
22	Z-EB450-022	CROSS HEAD SCREW	4
23	Z-EB450-023	CROSS HEAD SCREW	4
24	Z-EB450-024	HEX NUT	12
25	Z-EB450-025	HEXAGONAL HEAD SCREW	6
26	Z-EB450-026	UPPER CONNECTING SUPPORTING PLATE	2
27	Z-EB450-027	BACK BOX	1
28	Z-EB450-028	CROSS HEAD SCREW	2
29	Z-EB450-029	CROSS HEAD SCREW	8
30	Z-EB450-030	NUT	8
31	Z-EB450-031	PLAIN WASHER	8
32	Z-EB450-032	WIRE CLIP	4
33	Z-EB450-033	STANDING PLATE	2
34	Z-EB450-034	CULLIS	2
35	Z-EB450-035	6203 SHAFT BEARING	2
36	Z-EB450-036	WHEEL AXLE	2
37	Z-EB450-037	SIDE PLATE	2
38	Z-EB450-038	LOCATION PLATE	2
39	Z-EB450-039	PRESS PLATE	2
40	Z-EB450-040	BOLT	8

688.145 **SALAMANDER -** SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
41	Z-EB450-041	NUT	12
42	Z-EB450-042	SPRING WASHER	6
43	Z-EB450-043	PLAIN WASHER	6
44	Z-EB450-044	SLIDING SHAFT	1
45	Z-EB450-045	NUT	8
46	Z-EB450-046	BEARING BLOCK	3
47	Z-EB450-047	SPROCKET SHAFT	2
48	Z-EB450-048	CHAIN	2
49	Z-EB450-049	S/S SCREW	3
50	Z-EB450-050	CHAIN PLATE	2
51	Z-EB450-051	BACK BOARD	1
52	Z-EB450-052	CROSS HEAD SCREW	10
53	Z-EB450-053	SS SCREW	5
54	Z-EB450-054	SS SCREW	8
55	Z-EB450-055	COUNTERBALANCE	1
56	Z-EB450-056	RUBBER BASE	2
57	Z-EB450-057	BEARING COLUMN	2
58	Z-EB450-058	LOWER PULLING PLATE	1
59	Z-EB450-059	POWER CORD JACKET	1
60	Z-EB450-060	POWER CORD	1
61	Z-EB450-061	GROUNDING SCREW	1
62	Z-EB450-062	BRONZE NUT	2