

680.045 **WARMHOUDVITRINE** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	ZSD600-1041	Decorative frame	1
2	ZSD600-1042	Top glass	1
3	ZSD600-1043	Top glass base B	1
4	ZSD600-1044	Top glass base A	1
5	ZSD600-1045	Shelf	1
6	ZSD600-1046	Side glass	1
7	ZSD600-1047	Door Glass	1
8	ZSD600-1048	Nail for glass	1
9	ZSD600-1049	Handle	1
10	ZSD600-10410	Door hinge	1
11	ZSD600-10411	Pillar A	1
12	ZSD600-10412	Pillar B	1
13	ZSD600-10413	LED light	1
14	ZSD600-10414	LED partition	1
15	ZSD600-10415	Shelf frame	1
16	ZSD600-10416	Right panel	1
17	ZSD600-10417	Heating element frame 2	1
18	ZSD600-10418	Power line	1
19	ZSD600-10419	Cable clip	1
20	ZSD600-10420	Switch	1
21	ZSD600-10421	Indicating Light	1
22	ZSD600-10422	Controller	1
23	ZSD600-10423	Protecting coil	1
25	ZSD600-10425	Adjustable feet	1
26	ZSD600-10426	Baseboard	1
27	ZSD600-10427	Electric box	1
28	ZSD600-10428	Electric cover	1
29	ZSD600-10429	Drawer	1
31	ZSD600-10431	Cable clip fixer	1

680.045 **WARMHOUDVITRINE** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
32	ZSD600-10432	Cable clip base	1
33	ZSD600-10433	Cable clip cover	1
34	ZSD600-10434	Thermostat 125°C	1
35	ZSD600-10435	Thermostat 150°C	1
36	ZSD600-10436	Probe pressing plate	1
37	ZSD600-10437	Plug-type fixer	1
38	ZSD600-10438	Rear panel	1
39	ZSD600-10439	Heating element	1
40	ZSD600-10440	Heating element frame 1	1
41	ZSD600-10441	Water receiver	1
42	ZSD600-10442	Front panel	1
43	ZSD600-10443	Left panel	1
44	ZSD600-10444	Grill	1
45	ZSD600-10445	Door buckle 1	1
46	ZSD600-10446	Door buckle 2	1